

NOTICE

This information applies only to the FTB-5230S, FTB-5240S and FTB-5240BP modules.

Transportation of the Modules



IMPORTANT


Keep this information close at hand, as it contains important details about your product.




CAUTION

- ▶ Always use the GP-10-055 or GP-NS-1783 cases when transporting the FTB-5230S and FTB-5240S modules, and the GP-10-091 case when transporting the FTB-5240BP module. EXFO does not recommend transporting the modules in a platform and/or in a case other than the one designed for your specific module.
- ▶ Handle the case with care when transporting the module.
- ▶ Please follow these guidelines. Modules damaged from rough handling during transport or shipment are not covered by any EXFO warranty.

The following images show the GP-10-055, GP-10-091 and GP-NS1783 with their respective module inside.



FTB-5240BP module
GP-10-091 case



FTB-5230S or FTB-5240S module
GP-10-055 case



Place the FTB-5230S or FTB-5240S module in this location, with the input port and handle towards the left.

GP-NS-1783 case